




## INSTRUCTIONS

### CONDITION OF FLOOR

### DESIRED FINISHED LOOK

	Dull Honed Finish	Satin Honed Finish	High Gloss Polish	Extra High Gloss
Heavily Damaged Floors	Step 1 Step 5	Step 1 & 2 Step 5	Step 1, 2, 3 & 4 Step 5	Step 1, 2, 3 & 4 Step 5 Step 5 (dry)
Moderate Scratches	Step 2 Step 5 (to dull hone)	Step 1 & 2 Step 5 (to satin hone)	Step 2, 3 & 4 Step 5	Step 2, 3 & 4 Step 5 Step 5 (dry)
Light Scratches	Step 5 (to dull hone)	Step 5 (to satin hone)	Step 3 & 4 Step 5	Step 3 & 4 Step 5 Step 5 (dry)
Slightly Dull Finish	N/A	Step 5	Step 4 Step 5	Step 4 Step 5 Step 5 (dry)
Routine Maintenance	Step 5	Clean with Red Pad	Step 5	Step 5 Step 5 (dry)

*\*Always use the Orbot weight kit with the StoneFlash Pads.*

*\*All Steps must be used with water only. Step 5 can be used DRY as an additional step to increase the gloss. Make sure floor is dry. (see column "Extra High Gloss")*

*\*Always rinse thoroughly before starting and between steps with a squeegee wand. The smallest amount of debris can create problems and reduce optimal results.*

*\*Always move the Orbot front to back which is 1 complete pass. Softer stone flooring require at least 3 passes as harder stone flooring may require approximately 5 passes. Move Orbot approximately 1-3 seconds per foot length, the slower the better.*

*\*Always rinse pads after use and store in breathable bag or box.*



StoneFlash Pads - Step 1



StoneFlash Pads - Step 2



StoneFlash Pads - Step 3



StoneFlash Pads - Step 4



StoneFlash Pads - Step 5